



# Controller Setup

## Inkbird Controller



**Reset/Exit Button-**  
Exits Setting mode



**Set Button-**  
Press and hold S to gain access to menu codes



**Up Arrow-**  
Scrolls Temperature up



**Down Arrow-**  
Scrolls Temperature down

### Setup and Programming

1. Press and hold S to gain access to menu codes
2. Use arrows to select a menu code, press set to access the selected menu code
3. Use arrows to change the setting
4. Press power button to save settings and exit

**\*\*\*It is extremely important to set PT to 2 or higher to avoid short cycling the compressor and damaging the unit.**

## Menu Codes:

**TS** Temperature Setting

**HC** Heat OR Cool (this is a logic setting on how the thermostat will operate, the chiller will not heat anything)

**CF** Celsius OR Fahrenheit (beware - changing this resets all other settings, you must go back and set PT)

**CA** Calibration

**PT** Time Delay on compressor (must be set to 2 or higher to avoid damaging unit)

**AL** Low temp shutoff (not used, leave at default)

**AH** High temp shutoff (not used, leave at default)

**DS** Temperature dead-band