



# Controller Setup

## ITC 2000



**Reset/Exit Button-**  
Exits Setting mode



**Set Button-**  
Press and hold S to gain access to menu codes



**Up Arrow-**  
Scrolls Temperature up



**Down Arrow-**  
Scrolls Temperature down

### Setup and Programming

1. Press and hold S to gain access to menu codes
2. Use arrows to select a menu code, press set to access the selected menu code
3. Use arrows to change the setting
4. Press power button to save settings and exit

**\*\*\*It is extremely important to set PT to 2 or higher to avoid short cycling the compressor and damaging the unit.**

### Menu Codes:

<b>tS</b>	Temperature Setting
<b>CF</b>	Celsius OR Fahrenheit (beware - changing this resets all other settings, you must go back and set PT)
<b>CA</b>	Temperature Calibration
<b>Pt</b>	Time Delay on compressor (must be set to 2 or higher to avoid damaging unit)
<b>dS</b>	Temperature deadband (temp difference between when unit turns ON vs OFF)